




KD - 30T  
do 10-2012



**KD - 30T**  
**do 10-2012**

KD - 30T	
Pozice	Kód
1	501100120
2	501100150
3	501100100
4	451100130
5	451100140
6	451100150
7	451100160
8	451100170
9	450155210
10	451100220
11	451008600
12	451008700
13	500113500
14	401500550
15	401515200
16	402503000
17	402593000
18	402595000
19	407803200
20	407810100
21	408015020
22	408015030
23	408015040
24	408015060
25	408701500
26	408701700
27	408701850
28	408702400
29	408702600
30	401025000
31	451100230
32	451100235
33	408015070
34	501100160
35	407803210

# Exploded view

TABLE A: LABELS

MODEL	CODE	NOTE
VT	402594273	
TO - 940	402594234	Switch
TO - 940	402594235	Timer
TO - 960	402594234	Switch
TO - 960	402594235	Timer
TO - 920	402594233	Switch
TO - 920	402594235	Timer
TO - 930	402594233	Switch
TO - 930	402594235	Timer
VEC	402594241	
PM - LTF	402594244	
KD	402594243	
FP - 36	402594237	
FP - 66		
FP - 37		
FP - 67		
FT	402594247	
PD		
PM		
PS		
FP - 38		
FP - 68		
FE	402594272	
BM	402594236	
BMV		
HD		
WE		
WEV		
OTS		
UH		
BM-D	402594271	
SE		
CW		
GV		

