


## ROZKRES 1/1



OZNAČENÍ	POLOŽKA	ČÍSLO
1	Humidifier pipe	2030143
2	Cavity temperature probe	6000093
3	Motor shaft seal	6090171
4	Motor 1ph 230V	6033157
5	Cooling fan	6033176
6	Oven fan 200x51	5901132
7	Heating element 3000 W	6002113
8	Schuko plug+cable	6060023
9	Safety thermostat	6011117
10	Contactora 20A	6046044
11	Anti interference filter	6090060
12	Buzzer	6010182
13	Oven main board	6010231
14	ON/OFF switch	6032023
15	USB 2.0	6060045
16	Door microswitch	6043080
17	Cooking tray	2130099
18	Black oven seal	7070229
19	Cooling fan	6033171
20	Touch screen board	6010225
21	Touch screen cable	2030202
22	Hinge bushing	2030097
23	Complete door with glass	2030271GK
24	Door Handle	5900297
25	Spring 09x14	5900097
26	Magnet	5900351
27	Door magnet catch	2030096
28	Door spacer	2030095
29	Tray GN 1/2 polycarbonate	2103340
30	Tray closing glass	2030102
31	Led light	6061082
32	water pump	6042148
33	Nut M10 H5	5340016
34	Adjustable feet	5900008
35	Front panel + "H2O" glass	2030272
36	Heating element gasket	2027323